

Customer: ..... Contact: ..... Date: .....  
 Machine type: ..... SN machine: ..... SA-Nr.: .....  
 Service engineer: .....

OK

### 1. Software

Check version and update if necessary (latest version: 2.30.156)

(Attention: deinstall the old version completely incl. config file.  
 Afterwards install the latest version with „Default settings“)

### 2. Firmware

Check version and update if necessary (latest version: 1.0.800)

### 3. Machine settings

- Vacuum table mounted true  false
- MKHP plate mounted true  false
- Camera type -----
- Camera lens type -----

4. Determine Camera Head Offset

5. Teach tool-holder positions

6. Measure depth limiter ----- mm

### 7. Fault description